

Exam Reader 2



GET THE RESULTS YOU DESERVE

Specifically designed for use in tests and exams when a student requires reading assistance.

C-PEN Exam Reader 2 the successor our successful ExamReader. Exam Reader 2 is a convenient portable off-line assistive text reader for printed text. Everything, including the natural speaking voices, is embedded in this off-line device and there is no need for a computer or an internet connection. This means that students who have reading difficulties such as dyslexia can independently take exams knowing that they can read and understand the questions.

By using Exam Reader 2, schools don't have to invest in human readers or extra rooms, saving money to spend on other supporting resources instead. Exam Reader 2 is approved for use in exams by various exam boards, like The Joint Council for Qualifications (JCQ) in UK. Check with your special educational needs coordinator about availability in your school.

C-Pen Exam Reader 2 features

- Supports 10+ languages.
- Reads text out aloud in all supported languages.
- An off-line closed system with no opportunity to store any personalised assistive content.
- Audio aided user interface
- Fast reading for better productivity
- Audio boost
- Speaker and earphone jack.
- Rechargeable battery sufficient for a full day use.
- Cost efficient assistive solution for schools.



Scanning pens are essentially digital highlighter or mark-up pens. But takes you one step further. A scanning pen digitizes the printed information and allows it to be processed further which makes it possible to use for multiple purposes. The ones important to us are productivity and learning.



cpen.com

“READ-ALoud TOOLS SUCH AS TEXT-TO-SPEECH CAN BE A KEY TO UNLOCKING A STUDENT’S POTENTIAL.” WOOD AND KEELOR, 2020



CONTENT OF BOX

- Exam Reader 2
- Carry Case
- USB Cable
- Earphones
- Quick start guide

SUPPORTED LANGUAGES*

OCR & TextToSpeech

British English, American English, Australian English, Indian English, French, Canadian French, German, Italian, Spanish, Latin American Spanish, Swedish, Danish, Norwegian, Dutch, Flemish Dutch, Portuguese, Brazilian Portuguese, Russian, Mandarin, Cantonese

USER INTERFACE*

- English, French, German, Italian, Spanish, Swedish, Danish, Dutch, Portuguese, Russian,
- Talking menu/audio user interface in all languages

* Subject to firmware version – see firmware details on cpen.com

TECHNICAL SPECIFICATION

- Screen OLED 256*64
- CPU 1.2GHz dual core
- AI based OCR
- Micro USB (charging)
- Earphone jack 3.5mm
- Battery 600mAh
- Scan Font Size Range 6.5 – 22 pt
- Certifications CE, UKCA, RoHS FCC
- Size Dimensions: 135*33*19mm
- Weight: 50g

C-Pen is the original high-quality state-of-the-art pen scanner. Founded in 1998 in Lund, Sweden, we develop and manufacture industry-leading scanning solutions that make it easy to process printed text, empowering people’s ability to read, understand and learn.



cpen.com